

Assembly Instructions For The Bent Oak Rocker

Tools Needed:

Screwgun
Phillips Head Bit

Parts List:

Seat Assembly (1)
Back Assembly (1)
Left Arm & Leg Assembly (1)
Right Arm & Leg Assembly (1)
Rockers (2)

Hardware:

1/4" x 2" Bolts (10)
2" Screws (4)
Allen Wrench (1)

- Step 1** Place the seat assembly on edge on the floor with the front slat facing down. Place the arm assemblies on the proper sides (with the curved part of the arm on the outside) and align the holes in the legs with the holes on the side of the seat assembly. Insert a 2" bolt in each hole, turn in with the Allen wrench and semi-tighten only. **(Do not fully tighten any bolts until all bolts are in the proper holes).**
- Step 2** Lay the back assembly down between the arms. Align the holes on the back of the arm with the holes in the side of the back assembly and fasten with two 2" bolts. (You might have to loosen the arm and leg assembly slightly so the back fits in between the arms). Now align the predrilled holes in the bottom of the back assembly with the predrilled holes in the back of the seat assembly & attach with the four 2" screws.
- Step 3** Attach the rockers to the leg assemblies by aligning the holes in the rockers with the holes in the legs. Fasten with four 2" bolts. Make sure you have the longer end of the rocker at the back of the chair. Now fully tighten all bolts with the Allen wrench.