

Assembly Instructions For The Poly Upright Adirondack Chair

Tools Needed For Assembly

7/16" Wrench
7/16" Socket
Screwgun

Parts List

Seat Assembly (1)
Back Assembly (1)
Right Arm & Leg Assembly (1)
Left Arm & Leg Assembly (1)
Support Braces (2)

Hardware

1/4" x 2-3/4" Carriage Bolts (4)
1/4" x 2-1/2" Lag Bolts (2)
1/4" Washers (2)
1/4" Flange Nuts (4)
2-1/2" Screws (6)

- Step 1** Lay out and identify all the parts and pieces.
- Step 2** Fasten the arm and leg assemblies to the seat assembly by lining up the holes in the legs with the holes on the side of the seat assembly. Insert the 2-3/4" bolts into the holes and put on the 1/4" flange nuts. Tighten with the 7/16" wrench.
- Step 3** Now take the back assembly and place it between the arms letting the bottom back support strip rest on the seat assembly. Line up the predrilled hole in the back of the arm with the small pilot hole on the end of the middle back support strip. Put a 1/4" washer on a 2-1/2" lag bolt and turn into the hole with the 7/16" socket. (Do not over tighten). You might need to loosen the nuts on the leg assemblies to fit the back in between the arms.
- Step 4** Now push the bottom of the back assembly up against the seat slats. Take two of the 2-1/2" screws and insert them into the predrilled holes on the bottom back support strip. Using the screwgun turn them into the seat assembly. Screws are self drilling.
- Step 5** Take a support brace and hold it between the two front legs lining up the predrilled holes in the legs with the small pilot hole on the end of the brace. Insert a 2-1/2" screw through the holes in the legs and turn into the brace with the screwgun. Fasten the other support brace in the same manner.

