

Assembly Instructions For The Cupholder

Tools Needed:

#2 Square Drive Bit
Power Screwgun

Parts List:

Cupholder (1 or 2)

Hardware:

1-1/2" Screws (4)
(2 per cupholder)

Before assembling your furniture turn the arm assembly piece upside down and attach the cupholder(s) to the bottom of the arm assembly at the desired location. Attach with two screws per cupholder.

For application to a poly folding adirondack chair make sure you place the cupholder where it does not interfere with the folding/reclining mechanism.

