

Assembly Instructions For The Mailbox Post

Tools Needed For Assembly:

7/16" Wrench or Socket

Parts List:

Long 4x4 Post (1)

Short 4x4 (1)

Angle Brace (1)

Hardware:

1/4" x 2-1/2" Lag Screws (6)

- Step 1** Lay out and identify all the parts and pieces.
- Step 2** Take the long post and lay it on the ground with the notch facing up. Now take the short 4x4 with the notch facing down, place it over the long post with the notches interlocking. Take two lag screws and insert in the predrilled holes. Turn in and tighten with the 7/16" wrench or socket. Now flip the post over and put two more lags in the predrilled holes in the other side and tighten.
- Step 3** Take the angle brace and put it under the short 4x4 and down to the long 4x4 post. Attach with two more lag screws. Insert in the predrilled holes in the angle brace and turn into the long and short 4x4 pieces with the 7/16" wrench or socket.

