



Assembly Instructions

Hickory Solid Wood End Table & Coffee Table



*Thank you for choosing **A&L Furniture Co.***

We hope that this piece brings you many years of enjoyment!

For help with assembling your furniture,
or if you have missing hardware, please email us at
help@aandlfurniture.com or call us at 866-896-5747

PARTS (included)

Ⓐ Table Top (1)



Ⓑ Table Legs (4)



HARDWARE (included)

Ⓐ 2³/₄" Bolts (4)



Ⓑ Allen Wrench (1)



STEP 1

Lay table top upside down on a flat clean surface. Hold the legs in place with the notch in the legs in against the table skirting (see photo 1) one leg at a time. Insert 2³/₄" bolts through the metal brackets in the corners of the table top and turn them into the metal inserts in the legs (see photo 2). Tighten using the provided Allen wrench. (Do not overtighten.) Once this is done set the table upright on the floor and check for stability. If it rocks adjust the levelers as needed (see inset photo). You should be able to turn these easily with your fingers. (If you cannot you may have to use pliers.)





photo 1



inset photo




photo 2