



*Assembly Instructions*

## **Traditional Table Set**




*Thank you for choosing **A&L Furniture Co.***

*We hope that this piece brings you many years of enjoyment!*

For help with assembling your furniture,  
or if you have missing hardware, please email us at  
[help@aandlfurniture.com](mailto:help@aandlfurniture.com) or call us at 866-896-5747

## PARTS (included)

(A) Table Top (1)



(B) Table Legs (2)



(C) Table Braces (2)



(D) Bench Tops (2)



(E) Bench Legs (4)



(F) Bench Braces (4)



## HARDWARE (included)

2 $\frac{3}{4}$ " Bolts (12)

(a)



2 $\frac{1}{2}$ " Lag Screws (12)

(b)



Allen Wrench (1)

(c)



## TOOLS NEEDED

Hammer

$\frac{7}{16}$ " Wrench or Socket

## STEP 1

Lay the table top upside down on a flat clean surface. Attach the table legs to the inside of the 2x2 cross supports on the bottom of the table top. (See photo 1.) Insert the 2 $\frac{3}{4}$ " bolts through the predrilled holes in the table legs and turn them into the metal inserts in the 2x2. (See photo 2.) Tighten with the Allen wrench. Do not overtighten!




Photo 1




Photo 2

## STEP 2

Attach the table braces placing one end against the table top and the other end against the horizontal crosspiece on the table leg. (See photo 3.) Insert 2 $\frac{1}{2}$ " lag screws through the predrilled holes in the table braces. (See photo 4.) Tap lightly with a hammer to start them into the table top. Tighten using  $\frac{7}{16}$ " wrench or socket. (They are self drilling and will not crack the wood.) **Do not overtighten** as this may cause them to break!




Photo 3




Photo 4

### STEP 3

Lay the bench tops upside down on a clean flat surface. Attach the bench legs to the inside of the 2x2 cross supports on the bottom of the bench tops. (See photo 5.) If the holes do not align the legs can be adjusted by pushing or pulling them to the proper position. Insert 2 $\frac{3}{4}$ " bolts through the predrilled holes in the bench legs and turn them into the metal inserts in the 2x2. (See photo 6.) Tighten using the Allen wrench. **Do not overtighten!**




Photo 5




Photo 6

### STEP 4

Attach the bench braces placing one end against the bench top and the other end against the horizontal crosspiece on the bench leg. (See photo 7.) Insert 2 $\frac{1}{2}$ " lag screws through the predrilled holes in the braces. (See photo 8.) Tap lightly with a hammer to start them into the bench top. Tighten using the  $\frac{7}{16}$ " wrench or socket. (They are self drilling and will not crack the wood.) **Do not overtighten** as this may cause them to break!




Photo 7




Photo 8

Set the benches upright on the floor. If they rock or wobble, loosen the bolts, put some weight on the bench and retighten.